

Common for FVA-M2ST, FVA-U4ST and FVA-U4BT



1. Place a finger on the device very softly like touching it.
2. Place a fingertip, not a tip of nail, to the end of hollow area.
3. Align the right side of finger with right near-infrared part.

※ In case you place your finger on a device with some pressure, the authentication process may be failed by preventing the blood flow.

It is ideal to place a finger similarly both for enrollment and authentication. Being careful to follow the procedures above at enrollment and it would make any subsequent operations easy.